

Furnace purity in perfection!



DDphoenix reviving cleaning powder

CLOSE TO YOU

20
YEARS

Dental
Direkt

The new reviving cleaning powder DD phoenix for perfect sintering results.



Order
now!

DD phoenix

reviving cleaning powder

Discoloration and contamination of the sintering objects are not uncommon and often lead to undesirable results in the daily laboratory routine. Concealed behind it, damaged heating elements cause diffusion of molybdenum from the heating elements into the chamber.

The new reviving cleaning powder DD phoenix takes these impurities from the furnace atmosphere, absorbs them and cleans the furnace constantly. The regular use of DD phoenix provides pure, color-consistent sintering results, prevents recurring deposits in the firing chamber and extends the working life of the heating elements. We recommend using the DD phoenix sintering tray due to the sintering activity of the cleaning powder.

Prevent discoloration and experience the benefits of DD phoenix:

- no greenish discoloration of sintering objects caused by molybdenum
- removal of color liquid deposits in firing chamber
- ensures reliable and pure sintering results

| order-no. | article |
|-----------|---------------------------|
| Z 010 | DD phoenix bottle à 200 g |

*Our general terms and conditions apply. All prices are net prices excl. VAT.
Price changes and delivery possibilities excepted.